




Stores: ChelinoBaby – Ormonde – JHB
ChelinoBaby – Fourways – JHB
ChelinoBaby – Woodmead Square – JHB
ChelinoBaby – Greenstone – JHB
ChelinoBaby – Menlyn – Pretoria
ChelinoBaby – Kolonnade – Pretoria
ChelinoBaby – Centurion – Pretoria
ChelinoBaby – Gateway – Durban
ChelinoBaby – Online – www.chelinobaby.co.za



Imported for :
ChelinoBaby Group of Companies.
No. 12 Kimberlite Road , Theta Ext 5 ,
Booysens Reserve , JHB , 2091. SA.
Tel: +2711 8352520
Info: info@chelinoplatinum.co.za


Hot Mom High Chair




Hot Mom

PLEASE CAREFULLY READ AND PROPERLY KEEP THE USER MANUAL FOR FUTURE REFERENCE. IT WILL DAMAGE THE PRODUCT AND AFFECT YOUR BABY'S SAFETY IF YOU DON'T FOLLOW ALL INSTRUCTIONS.

01/ Parts Drawing




02/ Parts Drawing




03/ Product List

- * Please carefully read and follow all instructions;
- * Please check whether you have received all parts before your use. In case of any deficiency, serious damage during transit or improper size, please do not use it and contact our customer service center to exchange or resend.




04/ Installation Instructions on the Base

- ① Remove the base support and there are 4 holes on both sides (as shown in the figure).
- ② Separately put four nuts in holes, and keep the arc side upwards;




- ① Aim the side with holes at the round holes on the base support;
- ② Align the support with the base's concave-convex design, then properly insert (holes on both sides should be overlapped).





05/ Installation Instructions on the Support Brace

- ① Install and tighten screws in the holes, and tighten screws on the other side, indicating a successful installation of the base;
- ② Please tighten the screws on both sides (refer to the following drawing).





- ① Remove the support brace and press the spring button against the ground (as shown in the figure) until the iron prop pops up.
- ② Aim the base cover and move through the iron prop until it reaches to the top.





06/ Installation Instructions on the Seat Chair

- ① Aim the support brace with iron prop at the hole on the base;
- ② Align the iron prop with the base's concave-convex design, then insert it into the hole.





- ① 1.Remove the cylinder cover and put it in the upper part of the base;
- ② Aim the raised part of the cylinder cover at the concaved part below, then rotate clockwise to the end to lock.




07/ Installation Instructions on the Seat Chair

- ① Remove the seat chair and put it in the upper part of the support brace that has been installed;
- ② Aim the seat chair at the raised part of the support brace.





- ① Screw and aim two short screws at the hole on the upper part, and tighten and aim the long screws at the hole below.
- ② The seat chair is properly installed after 4 screws are tightened well.





08/ Installation Instructions on the Footboard and Safety Strap

- ① Remove the footboard part and aim at the depression of the seat chair;
- ② Insert the footboard part into the depression of the seat chair until it fully fits.





- ① Remove a safety strap (as shown in the picture);
- ② Insert a safety strap into the card slot and check whether it has been properly inserted into both sides.




09/ Installation Instructions on the Footboard and Seat Cushion

- ① “1” and “2” separately refer to the position involving shoulder seat strap buckle (as shown in the figure below);
- ② Take and put the seat cushion in the corresponding position, pass the safety strap through the corresponding holes, then make the seat cushion and chair fit well.





- ① Take the tray, align with and insert into holes on the both sides of the seat chair until the small square fully fits;
- ② Please refer to the following diagrams involving the successful installation of the seat chair;





10/ Installation and use steps of the safety belt

- ① Knob down the button as indicated by the arrow to open the safety buckle and put the baby in.
- ② Buckle the shoulder strap and waist strap together as indicated by the arrow to form group 1.





- ① Insert the buckled shoulder strap and waist strap buckle near the safety buckle as indicated by the arrow and the group 1 is inserted from the other side.
- ② The effect after buckling the safety belt is as indicated by the figure.





11/ Height adjustment of tray and seat chair

- ① Keep pulling buckles on both sides of tray open to move tray and adjust the distance away from the seat chair.
- ② Release buckles until a proper space that is suitable for your baby is adjusted. Slightly move tray and it indicates a successful lock when it ratcheted.





- ① Lower the seat chair: Keep putting foot on the lift button and press the seat chair down. Release the button until you gain a suitable height.
- ② Heighten the seat chair: Keep putting foot on the lift button and the seat chair will slowly rise. Release the button until you gain a suitable height.



12/ Reverse Adjustment of Footboard and Seat Chair


- ① Keep pressing the footboard's rear button, and drag the footboard.
- ② Release until the position that is suitable for your baby is adjusted (as shown in the figure).



13/ Angle adjustment of the seat chair's backrest

Unfasten the lock catch on the back of the seat chair (as shown in the figure), and adjust the angle of the seat chair to a comfortable position. Please check whether the seat chair is locked firmly after it is locked.

Warning: The product is intended for children able to sit up unaided and up to 3 years or a maximum weight of 15 kg.



14/ WARNINGS

- Users and guardians should carefully read and properly keep this user manual prior to use for future reference to ensure your kids' safety. It may hurt your kids if you don't follow all instructions;
- Never leave the child unattended
- Guardians should leave your kids alone during use;
- Don't leave kids without wearing safety strap alone;
- Avoid all serious hurts and even death caused by falling or dropping;
- The highchair should work with seat cushion and safety strap to avoid any falling!
- Please properly use the safety strap and it isn't suitable for kids who can independently climb through the seat chair;
- Ensure that your kids are using the safety strap during the whole adjustment process such as height and inclined angle adjustment;
- The tray isn't designed for the purpose of fixing your kids in the seat chair;
- The vertical seat chair angle is only suitable for kids (6-36 months and 9-15KG weight). They can



15/ WARNINGS

sit up without extra assistance;

- Keep an eye on your children if you intend to put your kids into this highchair;
- Use this highchair after all accessories are properly installed and adjusted;
- Keep away from fire, heat, torch and gas fire;
- Please ensure that all users clearly know how to use this highchair;
- Only adults can open, adjust and store this highchair;
- Please ensure that the highchair has been completely installed and store all fixed parts before your use;
- Keep your kids away from the highchair during installation and disassembly, and ensure that no kids are playing nearby;
- Please ensure that all moved parts won't touch your kids during adjustment;
- Please ensure that all safety settings are in normal use status prior to your use;
- Do not use the highchair if it isn't fully installed. You can disassemble the highchair only when you want to save space during storage.
- Do not put your hands or backpacks in the tray

16/ WARNINGS

to avoid imbalance;

- Please termly check whether all safety settings are in normal condition;
- Immediately stop your use in case of any question or damage;
- Please termly check whether all parts are in good condition;
- Please use this highchair in the even surface. Do not tread on or climb through the highchair;
- Do not make children independently close to the highchair without any supervision, and avoid them to climb the highchair;
- Do not use the highchair if there is any damage or parts missing;
- Do not rotate the highchair during your kids' using;
- Each seat chair can only work with one kid;
- Keep out of reach of children when not in use, and this highchair can't serve as a toy;
- Keep kids away from dangerous sources such as cables and ropes;
- Do not leave your kids alone in the place near window and wall to avoid the issue that they may climb with the help of windows and walls, and

17/



WARNINGS



prevent any imbalance which will make them fall off;

- After sun exposure, please move the highchair in the cool place, then your kids can normally use it;
- Prevent long-term sun exposure to avoid any color fading of materials and textile fiber;
- Do not use all accessories or parts offered by other suppliers;
- Our company shall not be liable for all hurts or property loss caused by improper use;
- To make improvements, our company has rights to modify and improve the surface and performance without any prior notification to users or sellers;
- The vertical seat design is only suitable for kids who do not require any assistance.
- The child should be secured in the high chair at all times by the restraining system, both in the reclined and upright positions.
- It is recommended that the high chair be used in the upright position only by children capable of sitting upright unassisted.

18/



WARNINGS



• **IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.**

- Never leave the child unattended.
- Always use the restraint system.
- Falling hazard: Prevent your child from climbing on the product.
- Do not use the product unless all components are correctly fitted and adjusted.
- Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.
- Be aware of the risk of tilting when your child can push its feet against a table or any other structure.
- Statement not to use the product until the child can sit up unaided.
- Statement not to use the product if any part is broken, torn or missing.
- The product is intended for children able to sit up unaided and up to 3 years or a maximum weight of 15 kg.

19/



WARNINGS




- **FALL HAZARD:** Children have suffered severe head injuries including skull fractures when falling from high chairs. Falls can happen suddenly if child is not restrained properly.
- Always use restraints, and adjust to fit snugly.
- Tray is not designed to hold child in chair.
- Stay near and watch child during use.

Product Maintenance and Warranty

- Wet the sponge with warm water, then add some detergent to clean. You can also clean with other detergents without corrosive or chemical elements;
- For stubborn stains, suggest cleaning with coarse cleaning bubbles. Do not use products with any coarse gum with ammonia, bleach or alcohol;
- Do not forcefully treat the safety settings or any moving parts. Please read all instructions again in case of any questions.
- Lubricate with silicone oil in the moving parts.

21/ **Note**



HIGH CHAIR	LENGTH	75 CM	CARTON LENGTH	61 CM
HIGH CHAIR	WIDTH	62 CM	CARTON WIDTH	44 CM
HIGH CHAIR	HEIGHT	107 CM	CARTON HEIGHT	42.5 CM

WEIGHT 13 KGS

[illegible]